



Wamee Keyboard and Mice Cleaning Guide

Wamee keyboards and mice may be cleaned with most mild, non-abrasive solutions commonly used in the office or hospital environment including:

- Water
- Mild Soap
- 3% Hydrogen Peroxide solution
- 10% Clorox Bleach solution
- 70% Isopropyl Alcohol
- 91% Isopropyl Alcohol
- Santi-Care Quaternary Ammonium Germicide
- PDI Santi-Cloth HB Germicidal Disposable Wipes
- Windex glass cleaner
- Lysol disinfectant spray
- Lysol disinfectant all-purpose cleaner
- Virex Tb disinfectant cleaner
- Virex 256 disinfectant cleaner
- CaviCide disinfectant cleaner
- Oxivir Tb wipes
- 100% Ethanol (Ethyl Alcohol)
- Providone-Iodine Prep Pads
- Chlor-Clean Wipes

Wamee makes no claims regarding the efficacy of the listed chemicals or processes as a means for controlling infection. Consult your hospital's infection control officer.

Cleaning the device with detergent /disinfectant wipes:

1. RFID KEYBOARD ONLY: Depress the Function button and the F11 [CLEAN] key to lock the keys for cleaning.
2. WASHABLE KEYBOARDS & MICE: Unplug the keyboard.
3. Using the appropriate wipe, clean the entire surface of the keyboard.

Cleaning the device in dishwasher or with water or disinfectant solutions:

1. Unplug the device.
2. To prevent water from damaging the USB connector, securely fix the protective cap in place.
3. DISHWASHER: Place the device on the top shelf of a dishwasher and wash on a standard setting. Ensure the heated drying function is turned off, or remove before this starts.
4. WATER: Using warm water and disinfectant products thoroughly wash and rinse the device.
5. Shake the device to dry it. Wipe away excess water with a clean cloth, until the surface is dry.
6. Check there is no excess water around the USB connector and remove cap.
7. Reconnect the device USB to the extension USB provided. **WARNING:** Do not put a wet cable into the extension or into your computer. Leave to air dry at room temperature. Do not expose to heat.